

Fordonskörning på manöverområdet utanför tornets öppethållningstider/ Vehicle driving on maneuvering area outside the tower`s opening hours

Fordonskörning på manöverområdet kräver klarering från tornet.

När tornet är stängt och fordonsföraren ropar upp tornet på kanal 1 kommer ett automeddelande att höras "Ö-viks tornet är stängt" När svaret "Ö-viks tornet är stängt" erhållits är det tillåtet att köra ut på manöverområdet under egen uppsikt.

Om autosvar ej erhållits får tillträde till manöverområdet ej ske.

Det åligger alla fordonsförare som ska köra på manöverområdet att förvissa sig att det inte är någon planerad flygtrafik utanför flygtrafikledningens öppethållningstider som kommer att påverkas av fordonskörningen på manöverområdet,

Det är varje fordonsförarens ansvar att det inte uppstår någon flygsäkerhetsrisk när man beträder manöverområdet.

Vid osäkerhet kontakta tjänstgörande driftledare på tele 070-528 74 22

Vehicle driving on maneuvering area outside the tower`s opening hours

Vehicle driving on maneuvering area requires clearance from the tower

When the tower is closed and vehicle drivers call the tower on channel 1 an auto message will be broadcasted "Ö-viks tornet är stängt" (Ö-viks TWR is closed) and with this message you are allowed to enter the maneuvering area under own supervision.

If the auto message isn't heard or any response from the tower you are not allowed to enter the maneuvering area under any circumstances

It is the responsibility of all vehicle drivers who drives on maneuvering area to make sure that there is no planned air traffic outside the opening hours of air traffic control which will be affected by the vehicle driving on maneuvering area

It is the responsibility of all vehicle drivers to ensure that no flight safety risk arises when entering the maneuvering area.

In case of uncertainty contact the airport supervisor at +4670-528 74 22

Before access to maneuvering area a permission must always be granted by the air traffic control (Ö-vik TWR).